



LIGHT SYSTEM



BASIC CONTROLS

CYCLE THROUGH YOUR SETUPS

STAGE MODE STUDIO MODE



ACTIVATING SETUP PRESETS

STAGE MODE STUDIO MODE



SAVE SETUP OR CONFIG



OVERDRIVE/BOOST-DISTO & CONFIG MENU

CYCLE VALUES



EDIT VALUES



CONFIG MENU

BRIGHTNESS

BYPASS
Buffered
True Bypass

OS MODE
Stage
Studio
Midi

ACCESS THE CONFIGURATION MENU (WHILE IN BYPASS STATE)



ACCESS THE OVERDRIVE/BOOST-DISTO MENU (WHILE OVERDRIVE/BOOST IS ACTIVE)



BOOST/DISTO MENU

boost	gain	level
STEP	55	80

Boost/Disto configuration
OFF - disabled
STEP - enable with overdrive sequentially
ON - enable with overdrive
ONLY - enable without overdrive

Boost/Disto drive

Boost/Disto volume

OVERDRIVE MENU

ovdr	type	tone	out
75	AGe	78	47

Overdrive gain

Diodes type
aGe : asymmetrical Germanium
Ge : Germanium
Si : Silicium

Overdrive tone

Overdrive output

